


C-200 S/CS



(LO-027.00)

C-200 S/CS (LO-057.01)

| Spare part | Single spare part number | Assembly spare part number | Available in colour number |
|---------------------------|--------------------------|----------------------------|----------------------------|
| 1. Cover | | | |
| 2. Seat | | 23706 | 62 |
| 3. Hinge pin | 23707 | | 62 |
| <hr/> | | | |
| 4. Bowl | | | |
| <hr/> | | | |
| 5. Vacuumbreaker | 16833 | | |
| 6. Electric valve | | | |
| 7. Hose nut | | 23709 | |
| 8. Hose barb | | | |
| 9. O-ring | | | |
| 10. Nozzle | | 23710 | 62 |
| 11. Watertube | | | |
| 12. Watertube | | | |
| 13. Waterfuse bracket | | | |
| 14. Fuse | 21766 | | |
| 15. Reed switch | 23714 | | 62 |
| <hr/> | | | |
| 16. Screw | | | |
| 17. Bowl retainer bracket | | | |
| 18. Magnet basket | | | |
| 19. Bowl retainer bracket | | | |
| <hr/> | | | |
| 20. Base upper | | | |
| 21. Base lower | | | |
| <hr/> | | | |
| 22. Handle | | | |
| 23. screw | | 23713 | 74 |
| 24. Bushing | | | |
| 25. Seal handle | | | |
| 26. Link | | | |
| 27. Saddle | | | |
| 28. Saddle bracket | 23848 | | |
| 29. Console | | | |
| 30. Led C-200 S and CS | 23718 | | |
| 31. Switch panel | | | |
| 32. Flush switch | 23716 | | |
| 33. Bezel | | 23846 | |

Cassette