



LE:1169_Porta Potti 145-165_0514-V01

	Spare part number	Spare part number	Spare part number	Colours available
1	Cover		07331	68
2	Seat			
3	Waterfill cap	12901		79
4	Flush-water tank <i>excl. seat & cover</i>			
5	Bellow	07862		62
6	Inlet tube		07024	
7	Check valve body			
8	Check valve flapper			
9	Flush tube		07031	62, 79
10	Spring seal plunger			
11	O-ring			
12	Nozzle			
13	Clasp handle			
14	Clasp spacer			
15	Screw			
16	Pour out spout	07492		62
17	O-ring		16195	
18	Capseal		07493	62
19	Dump cap			
20	Vent seal	07102		
21	Vent button		07524	62, 79
22	Spring			
23	Seal retainer		07475 PP145	44
24	Waste-holding tank			
25	Valve handle			
26	Boot seal			
27	Blade			
28	Retainer			
29	Lipseal	07101		
30	Clip retainer			
31	Clasp spacer			
32	Screw			



LE1171_Porta Potti 335-345-365_0514-V01

	Spare part number	Spare part number	Spare part number	Colours available
1	Cover			
2	Seat			
3	Waterfill cap	12901		79
4	Flush-water tank			
5A	Bellow	07862		62
		25817		79
5B	Piston pump > Aug 2005	PP335	25818 PP345-365	44, 68, 79
6	Inlet tube		07016 PP335	
7	Check valve body		07024 PP345-365	
8	Check valve flapper			
9	Flush tube			
10	Spring-seal plunger		07031	62, 79
11	O-ring			
12	Nozzle			
13	Clasp handle			
14	Clasp spacer			
15	Screw			
16	Pour out spout		07492	69, 88
17	O-ring			
18	Capseal	16195		
19	Dump cap		07493	62
20	Vent seal	07102		
21	Vent button			
22	Spring		07524	62, 79
23	Seal retainer			
24	Waste-holding tank			
25	Bezel			
26	Lens			
27	Weight			
28	Decal level indicator			
29	Dial			
30	Magnet			
31	Float arm	21322		
32	Valve handle			
33	Boot seal			
34	Blade			
35	Retainer			
36	Lipseal	07101		
37	Clip retainer			
38	Clasp spacer			
39	Screw			



LE1172_Porta Potti-465_1014-V02

		Spare part number	Spare part number	Spare part number	Colours available
1	Cover				
2	Seat				
3	Waterfill cap	25804			79, 89
4	Flush-water tank				
5	Button housing	25806			79, 89
6	Pump housing	25807			79, 89
7	Flush tube				
8	Spring-seal plunger-pin			25808	79, 89
9	O-ring				
10	Nozzle				
11	Clasp handle				
12	Clasp spacer				
13	Screw				
14	Pour out spout		25809		88, 90
15	O-ring				
16	Capseal	16195			
17	Dump cap			25810	79, 89
18	Vent seal	07102			
19	Vent button				
20	Spring			07524	79, 89
21	Seal retainer				
22	Waste-holding tank				
23	Bezel				
24	Lens				
25	Weight				
26	Decal level indicator				
27	Dial				
28	Magnet				
29	Float arm	21322			
30	Valve handle				
31	Boot seal				
32	Blade				
33	Retainer				
34	Lipseal	07101			
35	Clip retainer				
36	Clasp spacer				
37	Screw				

Colour Numbers	Description	Colour reference
06	Slate Grey	RAL 7015
07	Traffic Grey	RAL 7042
10	Ivory-United States	Not available
16	Turquoise Green	RAL 6016
30	Mocha	NCS S 2005-Y40R
38	Grey Beige	RAL 1019
44	Beige-Europe	PMS 05543P
47	White/Silver	Not available
57	Creamy White	RAL 9001
62	White/Grey	Not available
66	Light Ivory	RAL 1015
68	Grey White	RAL 9002
74	Moon Grey	Pantone 417
78	Yellow	RAL 1003
79	Edelweiss	Ideal-Std. 46
88	Grey-Brown	Not available
89	Granite	Not available
90	Anthracite Grey	RAL 7016
92	Orange	Not available
111	Signal White	RAL 9003
127	White	NCS S 0300-N
130	Ruby Red	RAL 3003
132	Signal Black	RAL 9004
133	Agate Grey	RAL 7038
135	Light Grey Granite	Not available