

# MODEL = RM6501

## POPULAR SPARE PARTS

<u>CABINET</u>		<u>LEISURE SPARES PART NUMBER</u>
	UPPER SHELF	= IC10368A
	LOWER SHELF	= IC10368A
	FREEZER DOOR	= 2932404029
	FREEZER UPPER SHELF	= IC10375
	FREEZER LOWER SHELF	= IC10368B
<u>DOOR</u>		
	TRAVEL CATCH	= TR10420
	TRAVEL CATCH BRACKET	= TR10420A
	UPPER SHELF	= IC10355
	MIDDLE SHELF (FULL WIDTH)	= IC10354
	BOTTLE SHELF	= IC10354
	BOTTLE BAR	= IC10354A
	BOTTLE FINGERS	= IC10331
	SALAD CRISPER	= 2932374016
<u>GAS / ELECTRIC ZONE</u>		
	THERMOCOUPLE	= GR10028
	240V ELEMENT	= EL10296B
	12V ELEMENT	= 173767013
	GAS VALVE	= 2931656017
	THERMOSTAT GAS	= 2931336016
	ELECTRONIC IGNITER	= IG10227
<u>COOLING ZONE</u>		
	JUNKERS BURNER	= JB10076
	SPARK ELECTRODE	= 2930379009
	JET 51	= 2007419175
	IGNITION LEAD	= 2931360057
<u>MISC</u>		
	THERMOSTAT KNOB	= CK10525A
	GAS KNOB	= CK10525

OTHER PARTS ARE AVAILABLE , PLEASE CONTACT LEISURE SPARES 01423 321108