





		Spare part number	Spare part number	Colours available
1	Glass lid	<i>Refer to page 5</i>		
2	Glass lid hinges 2x	SSPA0010		
3	Pan support (Wire)	SSPA0952		
	Pan support (Cast)	SSPA0951		
4	Pan support clips 6x	SSPA0800		
	Pan support clips 50x	SSPA0047		
5	Burner assy medium (Gloss Cap)	SSPA0812		
	Burner assy medium (Matt Cap)	SSPA0131		
	Burner assy medium (Gloss Cap) AUS	SSPA0110		
6	Burner assy small (Gloss Cap)	SSPA0811		
	Burner assy small (Matt Cap)	SSPA0109		
7	Hob Thermocouples			
	Front Right	SSPA0690		
	Front Left	SSPA0691		
	Back Right	SSPA0688		
8	Spark electrode 4x	SSPA0323		
9	Bump stops 2x	SSPA0044		
10A	Gas tap burner 1x	SSPA0433		
10B	Gas tap grill	SSPA0474		
10C	Gas tap oven	SSPA0448		
11	Hotplate switch	SSPA0580		
12	Fan x1	SSPA0501		
13	Control knobs	<i>Refer to page 3</i>		
14	Thermal switch – Grill shutoff	SSPA0514		
15	Thermal switches - Fan	SSPA0513		
16	Spark ignition switch	SSPA0383		
17	Oven lamp Switch	SSPA0590		
18	Grill door	<i>Refer to page 3</i>		
19	Complete oven door	<i>Refer to page 4</i>		
20	Glass, inner door	SSPA0260		
21	Oven door seal	SSPA0060		
22	Oven shelf	SSPA0980		
23	Grill pan	SSPA2500		
24	Oven burner			
25	Electrode oven	SSPA0158	SSPA0190	
26	Thermocouple oven			
27	Grill burner			
28	Electrode grill	SSPA0648	SSPA0179	
29	Thermocouple grill			
30	Spark generator	SSPA0301		
31	Oven lamp	SSPA0560		
32	Hotplate	SSPA0553		
33	Shut off assembly			
	Production date: < 07-11-2018 (<E231V...)	SSPA0609		
	Production date: ≥ 08-11-2018 (≥E231V...)	SSPA0610		
34	Anti-rattle Kit	SSPA0085		

Control knobs

Control Knob sets



Spare part number	SSPA0900	SSPA0901	SSPA0933	SSPA0932
Colours available	Brushed-Nickel/Black (.BNK/BK)	Brushed Nickel (.BNK) Chrome (.CR)	Brushed Nickel (.BNK)	Chrome (.CR) Soft Touch Black (.BK)
Set quantity	6	6	6	6

Cladding styles

No cladding



Bottom cladding




Grill Doors


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5050.BKX	Clear	Black	No	N/A		Brushed Nickel
SMAO5050.BK01X	Clear	Black	No	N/A		Chrome
SMAO5050.BK02X	Clear	Black	Stainless	Bottom		Chrome
SMAO5050.BK03X	Clear	Black	No	N/A		Chrome
SMAO5050.BK04X	Clear	Black	No	N/A		Chrome
SMAO5050.BK05X	Clear	Black	No	N/A		Brushed Nickel
SMAO5050.BK06X	Clear	Black	No	N/A		Brushed Nickel

Oven door styles








Drop down oven doors





Left hinged oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5070.BKX	Clear	Black	No	N/A		Brushed Nickel
SMAO5070.BK01X	Clear	Black	No	N/A		Chrome
SMAO5070.BK02X	Clear	Black	Stainless	Bottom		Chrome
SMAO5070.BK03X	Clear	Black	No	N/A		Chrome
SMAO5070.BK04X	Clear	Black	No	N/A		Chrome
SMAO5070.BK05X	Clear	Black	No	N/A		Brushed Nickel
SMAO5070.BK06X	Clear	Black	No	N/A		Brushed Nickel

Left hinged oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5071.BKX	Clear	Black	No	N/A		Brushed Nickel
SMAO5073.BKX	Clear	Black	No	N/A		Chrome

Glass lid styles



Spare part number	Glass	Print	Profile Colour
SGL2115.BKX	Clear	Black	Black
SGL2116.BKX	Smoked	Black	Black
SGL2115.BSX	Clear	Black	Stainless
SGL2116.BSX	Smoked	Black	Stainless
SGL2117.BKX	Clear	Black	Black