



LE1347_SOH15XX

		Spare part number	Spare part number	Colours available
1	Pan Holder adjustable	SSPA0958		
2	Pan support	SSPA0959		
3	Burner assy (medium)			
	Prod date: < 28-02-13 (E059P...)	SSPA0130		
	Prod date: ≥ 01-03-13 (E060P...)	SSPA0812		
4	Thermocouple			
	Left	SSPA0677		
	Right	SSPA0677		
	Production date: ≥ 01-03-2013 (≥ E060P...)			
	Left	SSPA0680		
	Right	SSPA0680		
5	Fascia Sticker	SSPA0005		
6	Gas tap burner 1x			
	Prod date: < 28-02-13 (E059P...)	SSPA0432		
	Gas tap burner 2x			
	Prod date: ≥ 01-03-13 (E060P...)	SSPA0430		
7	Gas tap grill			
	Prod date: < 28-02-13 (E059P...)	SSPA0472		
	Prod date: ≥ 01-03-13 (E060P...)	SSPA0470		
8	Gas tap oven			
	Prod date: < 28-02-13 (E059P...)	SSPA0454		
	Prod date: ≥ 01-03-13 (E060P...)	SSPA0450		
9	Knobs (5X)	SSPA1206		.BK
10	Door seal	SSPA0065		
11	Glass, inner door	SSPA0258		
12	Oven door	SMAO0041		.BKX
13	Oven shelf 1x	SSPA0987		
14	Grill cradle 1x	SSPA0957		
15	Dish and Tray, oven meat	SSPA0999		
16	Grill pan	SSPA0993		
17	Oven burner	SSPA0195		
18	Thermocouple oven			
	Prod date: < 28-02-13 (E059P ...)	SSPA0637		
	Prod date: ≥ 01-03-13 (E060P...)		SSPA0623	
19	Electrode oven			
20	Thermocouple grill			
	Prod date: < 28-02-13 (E059P...)	SSPA0642		
	Prod date: ≥ 01-03-13 (E060P...)	SSPA0638		
21	Grill burner	SSPA0184		