




		Spare part number	Spare part number (kit)
1	Glass lid assembly	<i>Refer to page 4</i>	
2	Glass lid hinges (pair)	SSPA0010	
3	Lid shut-off assembly	SSPA0610	
4	Lid bump stops (pair)	SSPA0044	
5	Pan support.4B (cast)	SSPA0949	
	Pan support.4B (black)	SSPA0950	
	Pan support.DF (cast)	SSPA0951	
	Pan support.DF (black)	SSPA0952	
6	Pan support clips (6x)	SSPA0800	
	Pan support clips (50x-bulk pack)	SSPA0047	
7	Medium burner assembly (gloss cap)	SSPA0110	
	Medium burner assembly (matt cap)	SSPA0133	
8	Small burner assembly (gloss cap)	SSPA0811	
	Small burner assembly (matt cap)	SSPA0109	
9	Hob thermocouples		
	Front right	SSPA0688	
	Front left	SSPA0690	
	Back right	SSPA0689	
	Back left (for 4 burner cooker)	SSPA0687	
10	Hob spark electrodes (set of 4)	SSPA0327	
11	Spark generator	SSPA0300 (K1540 with hotplate)	SSPA0301 (K1520-K1540 gas only)
12	Spark ignition switch	SSPA0383	
13A	Burner gas tap	SSPA0433	
13B	Oven gas tap and thermostat (K1520)	SSPA0447	
13C	Grill gas tap	SSPA0474	
14	Hotplate control switch <i>*if fitted</i>	SSPA0581	
15	Control knobs	<i>Refer to page 4</i>	
16	Grill door	<i>Refer to page 5</i>	
17	Grill door bump stops (pair)	SSPA0044	
18	Grill pan and handle Trivet		SSPA2500
19	Grill burner		
20	Grill thermocouple	SSPA0650	SSPA0178
21	Grill spark electrode		
22A	Fan thermal switch (horizontal tabs)	SSPA0517	
22B	Fan thermal switch (vertical tabs)	SSPA0513	
23	Thermal switch (grill shut-off – horizontal tabs)	SSPA0518	
24	Cooling fan	SSPA0529	
25	Hotplate	SSPA0553	

Not illustrated

Fascia	Contact Thetford	
Anti-rattle kit	SSPA0085	
Hotplate sensor and wire kit	SSPA0531	
Hinge kit	SSPA0053	SSPA0087
	Left side opening	Right side opening

K1520 Cooker - SCK4XXXX(Z) only


27	Complete oven door	Refer to pages 5&6	
28	Oven inner glass	SSPA0262	
29	Oven door seal	SSPA0066	
30	Oven shelf	SSPA0980	
31	Oven burner	SSPA0649	SSPA0197
32	Oven spark electrode		
33	Oven thermocouple		
34	Forced fan	SSPA0528	
35	Oven lamp <i>*if fitted</i>	SSPA0560	
36	Oven lamp switch	SSPA0590	

Glass lid



Spare part number	Glass	Print	Profile colour	Protective strip
SGL2115.BKX	Clear	Black	Black	No
SGL2115.BSX	Clear	Black	Stainless	No
SGL2117.BKX	Clear	Black	Black	No
SGL2118.BKX	Clear	Black	Black	Yes & Frame
SGL2119.BKX	Clear	Black	Black	Yes

Control knobs



Spare part number	SSPA0900	SSPA0901	SSPA0933	SSPA0932
Colour suffix	Brushed-Nickel .BNK Black .BK	Matt Nickel .MNK Brushed-Nickel .BNK Chrome .CR Black .BK	Brushed-Nickel .BNK Chrome .CR	Chrome .CR Black .BK Brushed-Nickel .BNK
Set quantity	6	6	6	6

Grill Doors

No cladding




Bottom cladding




Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5060.BK01X	Clear	Black	No	N/A		Chrome
SMAO5060.BK02X	Clear	Black	No	N/A		Chrome
SMAO5060.BK03X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK04X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK05X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK06X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK07X	Clear	Black	No	N/A		Chrome
SMAO5060.BK08X	Clear	Black	No	N/A		Chrome
SMAO5060.BK09X	Clear	Black	No	N/A		Black


Oven doors

Drop down oven doors



Left hinged oven doors



Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Handle colour
Drop down						
SMAO5080.BK01X	Clear	Black	No	N/A		Chrome
SMAO5080.BK02X	Clear	Black	No	N/A		Chrome
SMAO5080.BK03X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK04X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK05X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK06X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK07X	Clear	Black	No	N/A		Chrome
SMAO5080.BK09X	Clear	Black	No	N/A		Black
SMAO5082.BK01X	Clear	Black	Yes	Bottom		Chrome
Left hinged						
SMAO5081.BK08X	Clear	Black	No	N/A		Chrome
SMAO5081.BK02X	Clear	Black	No	N/A		Chrome
SMAO5081.BK09X	Clear	Black	No	N/A		Black

Right hinged

SMAO5084.BK01X	Clear	Black	No	N/A		Chrome
----------------	-------	-------	----	-----	---	--------

~~XXXXX~~ is not available anymore