



Spare parts S 3004 P (05/2012-04/2018)

Item no.	Article no.	Description	Quantity	Unit
10	30030-89400	S 3002 (P)/S 3004 (P) heat exchanger	1	PC
20	30030-42700	Inspection glass cpl.	1	PC
50	10030-26500	O-ring 52 x 5 mm, VMQ, 40 Shore A	1	PC
60	10010-84500	PH screw DIN 7985 M4x8-4.8-A2K-Z	1	PC
90	30030-03600	Exhaust duct fitting AE 3	1	PC
110	30090-91800	S 3004 (P) base cpl.	1	PC
120	10010-66200	ST screw ISO 7049 ST5,5x25-A2K-C-Z	1	PC
130	30090-00043	S 3004 P piezo ignitor kit	1	PC
160	30090-20700	S 3004 control rod	1	PC
170	30090-93700	Bush control rod	1	PC
180	30090-00141	S 3004/S 5004 safety pilot valve kit	1	PC
200	30030-12200	Magnet inset	1	PC
210	30030-12000	Screw-in nut	1	PC
220	30090-09900	S 3004 (P)/5004 holder for heat detector	1	PC
230	30090-92200	S 3002 (P)/3004 (P) burner cpl. 30 mbar	1	PC
280	10010-71300	ST screw ISO 14585 ST2,9x9,5-A2K-C	1	PC
290	30090-91300	S 3004/5004 thermocouple	1	PC
300	30090-92300	S 3004 P ignition electrode, 105 cm	1	PC
310	30010-23500	Flat connector 2.8 mm	1	PC
320	30030-04300	Extension cpl.	1	PC
330	30030-17500	Perforated plate	1	PC
340	30030-28500	Extension spring	1	PC

Spare parts S 3004 P (05/2012-04/2018)

Item no.	Article no.	Description	Quantity	Unit
350	30030-16400	S 3002/S 3004 frame	1	PC
360	10170-00	Elbow union 8 mm	1	PC
380	10010-68000	PH chipboard screw 3x12-A2K-Z	1	PC
390	30070-11500	Spring nut	1	PC
400	30090-95800	S 3004 installation box	1	PC
420	30090-02400	S 3004 accessory kit	1	PC