







LE1310\_SOG70XXX\_ELECTRIC\_SPARK



|    |                                                    | Spare part number                      | Spare part number                                            | Colours available |
|----|----------------------------------------------------|----------------------------------------|--------------------------------------------------------------|-------------------|
| 1  | Oven/grill tap                                     |                                        |                                                              |                   |
|    | <i>Production date: &lt; 16-02-07 (2007015002)</i> | SSPA0455                               |                                                              |                   |
|    | <i>Production date: &lt; 13-01-14 (E013R...)</i>   | SSPA0456                               |                                                              |                   |
|    | <i>Production date: ≥ 13-01-14 (E013R...)</i>      | SSPA0457                               |                                                              |                   |
|    | <i>Production date: ≥ 29-01-24 (E013R...)</i>      | SSPA0461                               |                                                              |                   |
| 2  | Control knob                                       | Refer to page 3                        |                                                              |                   |
| 3  | Ignition switch <b>*12V ignition models only</b>   | Refer to page 3                        |                                                              |                   |
| 4  | Light switch <b>*if fitted</b>                     | SSPA0591                               |                                                              |                   |
| 5  | Oven door seal                                     | SSPA0062                               |                                                              |                   |
| 6  | Piezo ignition <b>*if fitted</b>                   | Refer to page 3                        |                                                              |                   |
| 7  | Oven door (without handle/hinges)                  | Refer to page 4                        |                                                              |                   |
| 8  | Inner door glass                                   | SSPA0253                               |                                                              |                   |
| 9  | Oven shelf                                         | SSPA0982                               |                                                              |                   |
|    |                                                    | SSPA0980                               |                                                              |                   |
| 10 | Grill pan (full assy including trivet and handle)  | SSPA0993                               |                                                              |                   |
| 11 | Oven burner                                        |                                        |                                                              |                   |
|    | <i>Production date: &lt; 31-07-21 (E212Y...)</i>   | SSPA0191                               |                                                              |                   |
|    | <i>Production date: ≥ 01-08-21 (E213Y...)</i>      | SSPA0198                               |                                                              |                   |
| 12 | Oven spark electrode                               | SSPA0626<br>≥ 06-12-16<br>(E340T.....) | SSPA0606<br>< 06-12-16<br>(E340T...)<br><br>Modification kit |                   |
| 13 | Oven thermocouple                                  |                                        |                                                              |                   |
| 14 | Grill spark electrode                              | SSPA0627<br>≥ 06-12-16<br>(E340T.....) |                                                              |                   |
| 15 | Grill thermocouple                                 | SSPA0695<br>≥ 12-06-24                 |                                                              |                   |
| 16 | Grill door shut-off switch <b>*if fitted</b>       | SSPA0605                               |                                                              |                   |
| 17 | Grill burner                                       |                                        |                                                              |                   |
|    | <i>Production date: &lt; 26-10-15 (E299S...)</i>   | No longer available                    |                                                              |                   |
|    | <i>Production date: ≥ 26-10-15 (E299S...)</i>      | SSPA0185                               |                                                              |                   |
|    | <i>Production date: ≥ 29-01-24</i>                 | SSPA01104<br>SSPA0188                  |                                                              |                   |
| 18 | Spark generator                                    | Refer to page 4                        |                                                              |                   |
| 19 | Oven lamp <b>*if fitted</b>                        | SSPA0560                               |                                                              |                   |

XXXX is not available anymore

Control knobs

|                   |                                                                                   |                                                                                    |                                                                                     |
|-------------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Control Knob      |  |  |  |
|                   |                                                                                   |                                                                                    |                                                                                     |
| Spare part number | SSPA0916                                                                          | SSPA0911                                                                           | SSPA0920                                                                            |
| Colours available | Brushed-Nickel/Black<br>(.BNK)                                                    | Black (.BK)<br>Matt Nickel (.MNK)                                                  | Black (.BK)                                                                         |
| Set quantity      | 3,0                                                                               | 3,0                                                                                | 3,0                                                                                 |




Control knobs

|                   |                                                                                    |                                                                                     |
|-------------------|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
| Control Knob      |  |  |
|                   |                                                                                    |                                                                                     |
| Spare part number | SSPA0934                                                                           | SSPA0938                                                                            |
| Colours available | Satin (.SA)                                                                        | Black (.BK)<br>Matt Nickel (.MNK)                                                   |
| Set quantity      | 2                                                                                  | 1                                                                                   |

Ignition switches

|                   |                                                                                     |                                                                                     |                                                                                       |
|-------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|                   |  |  |  |
|                   |                                                                                     |                                                                                     |                                                                                       |
| Description       | Ignition switch round                                                               | Ignition switch rectangular                                                         | Piezo ignition                                                                        |
| Spare part number | SSPA0380                                                                            | SSPA0381                                                                            | SSPA0382                                                                              |

## Spark generator



| Description       | 4 terminals, 2 blanks        | 6 terminals | 6 terminals |
|-------------------|------------------------------|-------------|-------------|
| Spare part number | <del>SSPA0303</del> SSPA0300 | SSPA0399    | SSPA0301    |

## Oven doors (without handle and hinges)

| Spare part number | Glass               | Print | Cladding | Cladding Position | Handle Style | Hinges   |
|-------------------|---------------------|-------|----------|-------------------|--------------|----------|
| SMAO3435.BK99X    | Clear               | Black | No       | N/A               | N/A          | SSPA1791 |
| SMAO3435.BK97X    | Clear               | Black | Yes      | Bottom            | N/A          | SSPA1791 |
| SMAO3435.MIR99X   | Mirror              | Black | No       | N/A               | N/A          | SSPA1791 |
| SMAO3435.SS99X    | Sparkling stainless | Black | No       | N/A               | N/A          | SSPA1791 |

## Handles oven doors

| Spare part number                     | Centres (mm)<br>handle fixings | Handle Style                                                                          | Handle Colour |
|---------------------------------------|--------------------------------|---------------------------------------------------------------------------------------|---------------|
| SSPA1053 HANDLE.T-BAR 12mm            | 390 CRS                        |  | Stainless     |
| SSPA1056 HANDLE ALPS 60-CHROME OX     | 390 CRS                        |  | Chrome        |
| SSPA1060 HANDLE. V CUT. BRIGHT NICKEL | 390 CRS                        |  | Bright Nickel |
| SSPA1064 HANDLE HEADON BLACK          | 390 CRS                        |  | Black         |

XXXX is not available anymore