





LE1363\_SOH74XXX



|    |                                                       | Spare part<br>number | Spare part<br>number    | Colours<br>available |
|----|-------------------------------------------------------|----------------------|-------------------------|----------------------|
| 1  | Glass lid ( <b>BK:</b> <del>smoked black</del> clear) | SSPA0234             |                         | .BK                  |
|    | Glass lid ( <b>SBK:</b> solid black)                  | SSPA0233             |                         | .SBK                 |
| 2  | Glass lid hinges (2x)                                 | SSPA0010             |                         |                      |
| 3  | Pan support                                           | SSPA0967             |                         |                      |
| 4  | Pan support clips (4x)                                | SSPA0041             |                         |                      |
|    | Pan support clips (50x)                               | SSPA0042             |                         |                      |
| 5  | Bump stops (2x)                                       | SSPA0040             |                         |                      |
| 6  | Burner assy medium                                    | SSPA0114             |                         |                      |
| 7  | Burner assy large                                     | SSPA0123             |                         |                      |
| 8  | Spark electrode (4x)                                  | SSPA0310             |                         |                      |
| 9  | Thermocouples hob                                     |                      | <b>For lid shut off</b> |                      |
|    | Front left                                            | SSPA0675             | SSPA0671                |                      |
|    | Front right                                           | SSPA0675             | SSPA0671                |                      |
|    | Rear left                                             | n.a.                 | n.a.                    |                      |
|    | Rear right                                            | SSPA0676             | SSPA0670                |                      |
| 10 | Gas tap oven                                          | SSPA0452             |                         |                      |
| 11 | Gas tap grill                                         | SSPA0472             |                         |                      |
| 12 | Spark ignition button (incl. switch)                  | SSPA0381             |                         |                      |
| 13 | Light switch <i>*not all models</i>                   | SSPA0591             |                         |                      |
| 14 | Gas tap burner (1x)                                   | SSPA0432             |                         |                      |
| 15 | Control knobs                                         | Refer to page 3      |                         |                      |
| 16 | Grill door                                            | Refer to page 3      |                         |                      |
| 17 | Oven door                                             | Refer to page 4      |                         |                      |
| 18 | Lower door <i>*only for 3/4 height</i>                | Refer to page 4      |                         |                      |
| 19 | Glass, inner door                                     | SSPA0253             |                         |                      |
| 20 | Oven door seal                                        | SSPA0062             |                         |                      |
| 21 | Oven shelf                                            | SSPA0980             |                         |                      |
| 22 | Grill pan                                             | SSPA0991             |                         |                      |
| 23 | Oven lamp <i>*not all models</i>                      | SSPA0560             |                         |                      |
| 24 | Oven burner                                           |                      |                         |                      |
|    | Production date: < 31-07-21 (E212Y...)                | SSPA0191             |                         |                      |
|    | Production date: ≥ 01-08-21 (E213Y...)                | SSPA0198             |                         |                      |
| 25 | Thermocouple oven                                     | SSPA0642             |                         |                      |
| 26 | Electrode oven                                        | SSPA0321             |                         |                      |
| 27 | Grill burner                                          |                      |                         |                      |
|    | Production date: < 13-04-2015 (<E103S....)            | Not available        |                         |                      |
|    | Production date: ≥ 14-04-2015 (≥E104S....)            | SSPA0185             |                         |                      |
| 28 | Thermocouple grill                                    |                      |                         |                      |
|    | Production date: < 01-07-2015 (<E182S....)            | SSPA0643             |                         |                      |
|    | Production date: ≥ 02-07-2015 (≥E183S....)            | SSPA0644             |                         |                      |
| 29 | Electrode grill                                       | SSPA0321             |                         |                      |
| 30 | Spark generator                                       | SSPA0399             |                         |                      |

XXXXX = not available anymore

Control knobs

|                          |                                           |                                                                                   |
|--------------------------|-------------------------------------------|-----------------------------------------------------------------------------------|
| <b>Control Knob sets</b> |                                           |  |
| <b>Spare part number</b> | SSPA0901                                  |                                                                                   |
| <b>Colours available</b> | Matt Nickel (.MNK)<br>Satin Chrome (.SCR) |                                                                                   |
| <b>Set quantity</b>      | 6                                         |                                                                                   |

Cladding styles


|                                                                                     |                                                                                     |                                                                                       |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
| <b>No cladding</b>                                                                  | <b>Side cladding</b>                                                                | <b>Behind handle cladding</b>                                                         |
|  |  |  |

Grill Doors


| Spare part number | Glass | Print  | Cladding          | Cladding Position | Handle Style                                                                          | Handle Colour |
|-------------------|-------|--------|-------------------|-------------------|---------------------------------------------------------------------------------------|---------------|
| SMAO3425.MIR2X    | Clear | Mirror | No                | N/A               |  | Chrome        |
| SMAO3425.BK4X     | Clear | Black  | Bottom Horizontal | N/A               |  | Stainless     |
| SMAO3425.BK1X     | Clear | Black  | No                | N/A               |  | Stainless     |

## Oven door styles


Drop down oven doors



Left hinged oven doors



Right hinged oven doors



## Drop down oven doors

| Spare part number  | Glass | Print      | Cladding | Cladding Position | Handle Style | Handle Colour  |
|--------------------|-------|------------|----------|-------------------|--------------|----------------|
| SMAO3445.BK/SVS10X | Clear | Faded dots | No       | N/A               |              | Satin          |
| SMAO3445.MIR2X     | Clear | Mirror     | No       | N/A               |              | Chrome         |
| SMAO3445.BK1X      | Clear | Black      | No       | N/A               |              | Stainless      |
| SMAO3445.BK2X      | Clear | Black      | Yes      | Bottom Horizontal |              | Stainless      |
| SMAO3445.BK16X     | Clear | Black      | No       | N/A               |              | Chrome         |
| SMAO3445.BK3X      | Clear | Black      | No       | N/A               |              | Brushed nickel |
| SMAO3445.BK9X      | Clear | Black      | No       | N/A               |              | Chrome satin   |

## Lower doors

| Spare part number        | Glass            | Print             | Cladding      | Cladding Position | Handle Style   | Handle Colour  |
|--------------------------|------------------|-------------------|---------------|-------------------|----------------|----------------|
| <del>SMAO3460.SSX</del>  | <del>Clear</del> | <del>Black</del>  | <del>No</del> | <del>N/A</del>    | <del>N/A</del> | <del>N/A</del> |
| <del>SMAO3460.MIRX</del> | <del>Clear</del> | <del>Mirror</del> | <del>No</del> | <del>N/A</del>    | <del>N/A</del> | <del>N/A</del> |
| SMAO3460.BKX             | Clear            | Black             | No            | N/A               | N/A            | N/A            |

~~XXXXX~~ = not available anymore