





LE1363_SOH74XXX

		Spare part number	Spare part number	Colours available
1	Glass lid (BK: smoked black clear)	SSPA0234		.BK
	Glass lid (SBK: solid black)	SSPA0233		.SBK
2	Glass lid hinges (2x)	SSPA0010		
3	Pan support	SSPA0967		
4	Pan support clips (4x)	SSPA0041		
	Pan support clips (50x)	SSPA0042		
5	Bump stops (2x)	SSPA0040		
6	Burner assy medium	SSPA0114		
7	Burner assy large	SSPA0123		
8	Spark electrode (4x)	SSPA0310		
9	Thermocouples hob		For lid shut off	
	Front left	SSPA0675	SSPA0671	
	Front right	SSPA0675	SSPA0671	
	Rear left	n.a.	n.a.	
	Rear right	SSPA0676	SSPA0670	
10	Gas tap oven	SSPA0452		
11	Gas tap grill	SSPA0472		
12	Spark ignition button (incl. switch)	SSPA0381		
13	Light switch <i>*not all models</i>	SSPA0591		
14	Gas tap burner (1x)	SSPA0432		
15	Control knobs	Refer to page 3		
16	Grill door (without handle)	Refer to page 3		
17	Oven door (without handle)	Refer to page 4		
18	Lower door <i>*only for 3/4 height</i>	Refer to page 4		
19	Glass, inner door	SSPA0253		
20	Oven door seal	SSPA0062		
21	Oven shelf	SSPA0980		
22	Grill pan	SSPA0991		
23	Oven lamp <i>*not all models</i>	SSPA0560		
24	Oven burner			
	Production date: < 31-07-21 (E212Y...)	SSPA0191		
	Production date: ≥ 01-08-21 (E213Y...)	SSPA0198		
25	Thermocouple oven	SSPA0642		
26	Electrode oven	SSPA0321		
27	Grill burner			
	Production date: < 13-04-2015 (<E103S....)	Not available		
	Production date: ≥ 14-04-2015 (≥E104S....)	SSPA0185		
28	Thermocouple grill			
	Production date: < 01-07-2015 (<E182S....)	SSPA0643		
	Production date: ≥ 02-07-2015 (≥E183S....)	SSPA0644		
29	Electrode grill	SSPA0321		
30	Spark generator	SSPA0399		

XXXXX = not available anymore

Control knobs




Control Knob sets		
Spare part number	SSPA0901	
Colours available	Matt Nickel (.MNK) Satin Chrome (.SCR)	
Set quantity	6	

Handles are being supplied separately; hinges only where applicable

Grill doors (without handle)

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Hinges
SMAO3425.MIR99X	Clear	Mirror	No	N/A	N/A	Yes
SMAO3425.BK99X	Clear	Black	No	N/A	N/A	Yes

Oven door styles

Drop down oven doors	Left hinged oven doors	Right hinged oven doors
		

Drop down oven doors (without handle and hinges)

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Hinges
SMAO3445.BK/SVS99X	Clear	Faded dots	No	N/A	N/A	SSPA1791
SMAO3445.MIR99X	Clear	Mirror	No	N/A	N/A	SSPA1791
SMAO3445.BK99X	Clear	Black	No	N/A	N/A	SSPA1791

Handle oven doors

Spare part number	Centres (mm) handle fixings	Handle Style	Handle Colour
SSPA1050 HANDLE PULL BOSS 418MM LONG SS	390 CRS		Stainless
SSPA1053 HANDLE.T-BAR 12mm	390 CRS		Stainless
SSPA1056 HANDLE ALPS 60-CHROME OX	390 CRS		Chrome
SSPA1060 HANDLE. V CUT. BRIGHT NICKEL	390 CRS		Nickel

Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3460.SSX	Clear	Black	No	N/A	N/A	N/A
SMAO3460.MIRX	Clear	Mirror	No	N/A	N/A	N/A
SMAO3460.BKX	Clear	Black	No	N/A	N/A	N/A