




LE1392_SOH76XXX


		Spare part number	Spare part number	Colours available
1	Glass lid (.BK: smoked black clear)	SSPA0243		
2	Glass lid hinges 2x	SSPA0010		
3	Shut off assy (=incl. nr 8)	SSPA0611		
4	Pan support	SSPA0967		
5	Pan support clips 4x	SSPA0041		
	Pan support clips 50x	SSPA0042		
6	Burner assy (large)			
	Production date: < 24-06-2012 (< E175N...)	SSPA0123		
	Production date: ≥ 25-06-2012 (≥ E176N...)	SSPA0813		
7	Burner assy (medium) 1.5 kW			
	Production date: < 24-06-2012 (< E175N...)	SSPA0114		
	Production date: ≥ 25-06-2012 (≥ E176N...)	SSPA0812		
8	Thermocouples hob		For lid shut	
	Rear left	SSPA0676	SSPA0671	
	Rear Right	SSPA0676	SSPA0670	
	Front	SSPA0675	SSPA0671	
	Production date: ≥ 25-06-2012 (≥ E176N...)		For lid shut	
	Rear Left	SSPA0682	SSPA0684	
	Rear Right	SSPA0682	SSPA0687	
	Front	SSPA0681	SSPA0685	
9	Spark electrode 4x			
	Production date: < 24-06-2012 (< E175N...)	SSPA0310		
	Production date: ≥ 25-06-2012 (≥ E176N...)	SSPA0320		
10	Bump stop 2x	SSPA0040		
11	Gas Tap Oven/grill			
	Production date: < 24-06-2012 (< E175N...)	SSPA0456		
	Production date: ≥ 25-06-2012 (≥ E176N...)	SSPA0457		
	Production date: ≥ 29-01-2024 (≥ E176N...)	SSPA0460		
12	Gas tap burner 1x			
	Production date: < 24-06-2012 (< E175N...)	SSPA0432		
	Production date: ≥ 25-06-2012 (≥ E176N...)	SSPA0430		
13	Gas tap burner (Large)			
	Production date: < 24-06-2012 (< E175N...)	SSPA0472		
	Production date: ≥ 25-06-2012 (≥ E176N...)	SSPA0470		
14	Control knobs	Refer to page 4		
15	Spark ignition switch	SSPA0381		
16	Light switch <i>*not all models</i>	SSPA0590		
17	Oven door seal	SSPA0062		
18	Oven door (without handle/hinges)	Refer to page 4		
19	Glass, inner door	SSPA0253		
20	Oven shelf 1x	SSPA0982		
		SSPA0980		
21	Grill pan	SSPA0993		

		Spare part number	Spare part number	Colours available
22	Spark generator	SSPA0399		
23	Electrode oven	SSPA0626 ≥ 06-12-16 (E340T...)	SSPA0606 < 06-12-16 (E340T...) Modification kit	
24	Thermocouple oven			
25	Thermocouple grill	SSPA0627 ≥ 06-12-16 (E340T...)		
26	Electrode grill	SSPA0695 ≥ 12-06-24 (E045A...)		
27	Grill shutoff	SSPA0605		
28	Grill burner			
	Production date: < 26-04-16 (E299S...)	Not available		
	Production date: ≥ 27-04-16 (E299S...)	SSPA0185		
	Production date: ≥ 29-04-24	SSPA01104 SSPA0188		
29	Oven Burner	SSPA0191		

~~XXXX~~ = not available anymore

Control knobs

Control Knob sets



Spare part number

SSPA1205

Colours available

Chrome (.CR)

Set quantity

6

Oven doors (without handle and hinges)

Spare part number	Glass	Print	Cladding	Cladding position	Handle style	Hinges
SMAO3445.BK99X	Clear	Black	No	N/A	N/A	SSPA1791
SMAO3445.MIR99X	Mirror	N/A	No	N/A	N/A	SSPA1791

Handles oven doors

Spare part number	Centres (mm) Handle fixings	Handle Style	Handle Colour
SSPA1057 HANDLE ALPS 30- BRUSHED INOX	390 CRS		Brushed Nickel