







LE1328_SOV70XXX

		Spare part number	Spare part number	Colours available
1	Oven tap			
	<i>Production date: < 08-11-11 (E312M...)</i>	SSPA0452		
	<i>Production date: > 08-11-11 (E312M...)</i>	SSPA0451		
2	Control knobs	<i>Refer to page 3</i>		
3	Ignition switch (rectangular or round)	<i>Refer to page 3</i>		
4	Oven seal	SSPA0062		
5	Piezo ignition (n.a. on all models)	<i>Refer to page 3</i>		
6	Oven door (without handle/hinges)	<i>Refer to page 4</i>		
7	Glass, inner door	SSPA0253		
8	Oven shelf	SSPA0982		
		SSPA0980		
9	Grill pan	SSPA0993		
10	Oven burner			
	<i>Production date: < 31-07-21 (E212Y...)</i>	SSPA0191		
	<i>Production date: ≥ 01-08-21 (E213Y...)</i>	SSPA0198		
11	Thermocouple oven	SSPA0642	SSPA0623	
		< 08-11-2011	> 08-11-2011	
12	Electrode oven	(E312M.....)	(E312M.....)	
13	Spark generator (n.a. on all models)	<i>Refer to page 3</i>		

~~XXXXXX~~ is not available anymore


Control knobs

Control Knob			
Spare part number	SSPA0934	SSPA0938	SSPA0920
Colours available	Satin (.SA)	Black (.BK) Matt Nickel (.MNK)	Black (.BK)
Set quantity	2	1	3

Ignition switches

		
Description	Ignition switch rectangular	Piezo ignition
Spare part number	SSPA0381	SSPA0382

Spark generator

	
Description	4 terminals, 2 blanks
Spare part number	SSPA0303

Handles are being supplied separately; hinges only where applicable

Oven doors (without handle and hinges)

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Hinges
SMAO3435.BK99X	Clear	Black	No	N/A	N/A	SSPA1791
SMAO3435.BK97X	Clear	Black	Yes	Bottom	N/A	SSPA1791
SMAO3435.MIR99X	Mirror	Black	No	N/A	N/A	SSPA1791

Handle oven doors

Spare part number	Centres (mm) handle fixings	Handle Style	Handle Colour
SSPA1053 HANDLE.T-BAR 12mm	390 CRS		Stainless
SSPA1056 HANDLE ALPS 60-CHROME OX	390 CRS		Chrome
SSPA1060 HANDLE. V CUT. BRIGHT NICKEL	390 CRS		Bright Nickel
SSPA1064 HANDLE HEADON BLACK	390 CRS		Black