




LEXXXX\_SHB176XX

		Spare part number	Colours available	
1	Glass lid (.BK: smoked black)	SSPA0222	.BK	
	Glass lid (.SBK: solid black)	SSPA0223	.SBK	
2	Hinge	SSPA0010		
3	Pan support	SSPA0978		
4	Pan Support Clip 4x	SSPA0041		
	Pan Support Clip 50x	SSPA0042		
5	Burner assembly (small)	SSPA0102		
6	Burner assembly (medium)	SSPA0114		
7	Burner assembly (large)	SSPA0123		
8	Hot plate	SSPA0550		
9	Knobs	<i>Refer to page 3</i>		
10	Gas taps (complete set)	SSPA0419		
11	Hot plate switch	SSPA0580		
12	Thermocouples			
	Front left	SSPA0675		
	Front right	SSPA0675		
	Rear Left	n.a.		
	Rear Right	SSPA0676		
	<b>Production date: ≥ 24-10-2017 (≥ E297U...)</b>			<b>For lid shut off</b>
	Front left	SSPA0680	SSPA0685	
	Front right	SSPA0680	SSPA0685	
	Rear Left	n.a.	n.a.	
	Rear Right	SSPA0682	SSPA0687	
	13	Electrode	SSPA0312	
	14	Fixation		
Production date: < 21/12/11 (E355N...)		SSPA0025		
Production date: ≥ 22/12/11 (E356N...)		SSPA0024		

Control knobs

Control Knob			
Spare part number	SSPA0901	SSPA0904	SSPA0939
Colours available	Matt Nickel (.MNK)	Black (.BK)	Black (.BK) With marks
Set quantity	6	6	4