






LE1315\_SOH44XXX

		Spare part number	Spare part number	Colours available
1	Glass lid ( <b>BK</b> : smoke black)	SSPA0235		.BK
2	Glass lid hinges 2x	SSPA0010		
3	Pan support	SSPA0961		
4	Pan support clips 4x	SSPA0041		
	Pan support clips 50x	SSPA0042		
5	Bump stops 2x	SSPA0040		
6	Burner assy (medium)	SSPA0114		
7	Burner assy (large)	SSPA0123		
8	Spark electrode 4x	SSPA0310		
9	Thermocouples			
	Front left	SSPA0676		
	Front right	SSPA0675		
	Rear right	SSPA0676		
10	Gas tap oven	SSPA0452		
11	Gas tap grill	SSPA0472		
12	Spark ignition button (=incl. switch)	SSPA0381		
13	Light switch <i>*not all models</i>	SSPA0591		
14	Gas tap burner 1x	SSPA0432		
15	Control knobs	<i>Refer to page 3</i>		
16	Grill door	<i>Refer to page 3</i>		
17	Oven door	<i>Refer to page 4</i>		
18	Lower door <i>*only for 3/4 height</i>	<i>Refer to page 4</i>		
19	Glass, inner door	SSPA0253		
20	Oven door seal	SSPA0062		
21	Oven shelf	SSPA0980		
22	Grill pan	SSPA0991		
23	Oven lamp <i>*not all models</i>	SSPA0560		
24	Oven burner	SSPA0191		
25	Thermocouple oven	SSPA0642		
26	Electrode oven	SSPA0321		
27	Grill burner			
	Production date: < 13-04-2015 (<E103S....)	Not available		
	Production date: ≥ 14-04-2015 (≥ E104S....)	SSPA0185		
28	Thermocouple grill	SSPA0644		
29	Electrode grill	SSPA0321		
30	Spark generator	SSPA0399		



**Control knobs**

<b>Control Knob sets</b>		
<b>Spare part number</b>	SSPA0900	SSPA0901
<b>Colours available</b>	Brushed- Nickel/Black (.BNK/BK)	Matt Nickel (.MNK) Satin Chrome (.SCR)
<b>Set quantity</b>	6	6

**Cladding styles**


<b>No cladding</b>	<b>Side cladding</b>	<b>Behind handle cladding</b>
		

**Grill Doors**


Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3415.BK18X	Clear	Black	No	N/A		Brushed Nickel
SMAO3415.BK15X	Clear	Black	No	N/A		Bright Nickel

Oven door styles


Drop down oven doors





Left hinged oven doors



Right hinged oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3435.BK20X	Clear	Black	No	N/A		Brushed Inox
SMAO3435.BK15X	Clear	Black	No	N/A		Brushed nickel

Lower doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO3450.BK	Clear	Black	No	N/A	N/A	N/A